

Fascia Trim

Attach fascia trim with galvanized flat screws or galvanized nails positioned to be under the drip edge. End lap fascia trim 1 inch minimum.

Drip Edge

Attach drip edge using galvanized flat screws or galvanized nails to temporarily hold in place straight. End lap drip edge 1 inch minimum.

