

## End Wall

Install outside profile closure with mastic prior to setting wall trim. Attach end wall trim with #9 X 1-1/2" metal to wood self-drilling screws through the outside closure at each rib. Attach vertical leg to wall substraight.

## Side Wall

Roof should be installed prior to siding. Install counter flashing and attach with roofing nails. Trim panel to fit within 1/2 inch of wall. Install sealant tape on panel and set side wall trim. Attach #9 X 1-1/2" metal to wood self-drilling sealing screws at 12" on center.

